

- E379-Turn-table Shaft for Portables~28T Fibre (2 $\frac{1}{2}$ " B. F.).
- E380-Turn-table Shaft for Motors #2~3 and 4~28T Fibre (2 $\frac{1}{4}$ " B.F.).
- E381-Turn-table Shaft for Type "B" Motor~28T Fibre (3 $\frac{1}{4}$ " B.F.).
- E394-Intermediate Driving Gear for Type "B" Motor.
- E395-Turn-table Shaft Only for Types "D" and "E" Motors.
- F424-Spring Box Shaft for 2-Spring Motors.
- F425-Spring Box Shaft for 3-Spring Motors.
- GL132-Winding Sleeve.
- GL133-Tongue-Clutch Sleeve.
- GL492-Pawl.
- GL494-Fibre Gear used with our E395.
- GL532-Driving Shaft and Pinion Complete used with our J446.
- GL535-Grooved-Sleeve.
- J446-Intermediate Gear Complete used with our GL532.
- J453-Winding Sleeve and Gear Complete.
- J474-Spring Barrel Winding Sleeve Complete for Type "B" Motor.

It's all for Brunswick and for every Brunswick.

PARTS
FOR
BRUNSWICK

Everybody's
T.M.Co.

PHILADELPHIA
U.S.A.

B221-Governor Ball and Spring Complete for Single Spring Motors~packed one dozen to the carton.

B222-Governor Ball and Spring Complete for all New Type Motors and Electric Pantropes~packed one dozen to the carton.

C477-Winding Shaft for our J558.

C478-Winding Shaft for our J559.

E511-Turn Table Shaft for New Type Single Spring Motors and Portable #101 (28T Fibec).

F426-Spring Barrel Winding Gear for Types "C," "D," "E," and all New Motors.

GL8-Governor Screw.

GL617-Spring Barrel Screw used with our S789.

GL716-Needle Screw for Electrical Pick-up on all Electric Pantrope Models.

GL727-Governor Washer for GL8.

GL737-Stationary Governor Collar used with our K368.

GL738-Sliding Governor Collar used with our GL737.

GL739-Retaining Spring used with our C477 and C478 (3/4" I.D.).

GL740-Spring Barrel Spacing Collar for Single Spring Motors.

GL741-Spacing Collar for our E511.

GL742-Winding Shaft Spring Clip used with our C477 and C478.

GL743-Spacing Washer for our C477 and C478.

J558-Spring Barrel Winding Gear for New Type Single Spring Motors and Portable #101~30T.


J559-Spring Barrel Winding Gear for Latest Type Single Spring Motors.

J560-Intermediate Gear Complete for Single Spring Motors used with our E511.

K368-Governor Spindle for All Type Motors.

S789-Spring Barrel Driving Gear for Single Spring Motors. 3/4" Center Hole (3 1/2" O.D.).


S790-Spring Barrel Shaft Complete used with our J558 and J559.



© E.T.M. Co., Inc.

PARTS
FOR
BRUNSWICK
Everybody's
T.M. & Co.
PHILADELPHIA
U.S.A.

The initials "O.D." signify Outside Diameter, "I.D." means Inside Diameter.



C430-Male Winding Shaft with Ratchet.

C431-Female Winding Shaft with Ratchet.

C432-Winding Shaft used with our F424.

C433-Winding Shaft used with our F425.

C445-Winding Shaft and Gear Complete used on Type B Motors.

C446-Winding Shaft for Type F Motors.

J445-Intermediate Gear Complete for Type C~D and E Motors.

J475-Driving Gear and Sleeve Complete for Type B Motors.

J476-Driving Gear and Sleeve Complete for Types C~D and E Motors.

J477-Intermediate Gear for Type F Motors and Portables used with our S454.

J478-Spring Box Shaft and Sleeve Complete for Motors #1, 2 and 4.

S454-Spring Barrel Driving Gear for Type "F" Motors and Portables.


Quite a few of the above items vary so closely that we respectfully ask you to read our description carefully.

PARTS
FOR
BRUNSWICK

Eveready's
T.M. & CO.

PHILADELPHIA,
U.S.A.

- B194-Governor Ball and Spring~
packed one dozen to the carton.
- B198-Governor Ball and Spring (large
lead ball) packed one dozen to
the carton.
- B199-Governor Ball and Spring (small
lead ball) packed one dozen to
the carton.
- B205-Governor Ball and Spring (steel
ball) packed one dozen to the
carton.
- B206-Governor Ball and Spring (brass
ball) packed one dozen to the
carton.
- GL 8-Governor Spring Screw.
- GL 20-Needle Screw for our N162~
N179 and N406.
- GL 25-Tension Spring for Sound Box.
- GL 26-Tension Spring used with our
GL42.
- GL 42-Tension Spring Screw.
- GL 53-Governor Spring Screw.
- GL208-Set Screw for Spring Shaft.
- GL422-Governor Spring Washer.
- GL454-Needle Screw for our N402.
- GL490-Intermediate Gear Bearing used
with J445.
- GL495-Governor Bearing.
- GL536-Screw for attaching our GL492.
- GL537-Spring Box Shaft Screw.
- GL541-Governor Spring Washer.
- GL542-Governor Bearing.
- GL543-Drive Shaft Bearing used with
our E394.
- GL544-Speed Regulator Tension
Spring.
- GL545-Governor Bearing Set Screw.
- GL546-Tone Arm Stop Screw.
- GL547-Governor Bearing Stop Screw.
- GL548-Tension Spring Screw.
- GL549-Spring Barrel Screw.
- GL552-Governor Bearing.
- GL553-Governor Bearing Eccentric.
- GL554-Governor Sliding Collar.
- GL555-Governor Stationary Collar.
- GL556-Motor Frame Screw.
- K368-Governor Spindle.
- N162-Needle Arm Complete for Swiss
Reproducer.
- N178-Needle Arm Complete.
- N179-Needle Arm Complete.
- N402-Needle Arm Complete for
Ultona.
- N406-Needle Arm Complete for #3
Reproducer.



PARTS
FOR
BRUNSWICK
AND **SONORA**

Everybody's
PARTS COMPANY

PHILADELPHIA
U.S.A.

Half and Half. The upper half are Parts for
Brunswick; the lower half for Sonora.